



Notes:

1. Windrow the existing topsoil from the foreslope to create a berm at the grading tie line.
2. Stabilize berms in accordance with the Construction General Permit.
3. Place weirs intermittently throughout the length of the berm to allow stormwater to drain through the berm.
4. Avoid placing weirs adjacent to waterbodies.
5. Install fiber rolls as the weirs are created in the topsoil berm.
6. Include costs to create, stabilize, maintain, and dismantle the berm in the unit price bid for "Topsoil".
7. Include costs for fiber rolls in the unit price bid for "Fiber Rolls 12IN" or "Fiber Rolls 20IN".

This document
is preliminary
and not for
construction or
implementation
purposes.

Temporary Topsoil Berm and Weir
Detail