



## SIGN PUNCHING, STRINGER AND SUPPORT LOCATION DETAILS REGULATORY, WARNING AND GUIDE SIGNS









Assembly No. 38










Assembly No. 39











Assembly No. 40

## D-754-33

Notes:

- 1. Use 0.100 inch minimum thickness sign backing material.
- 2. Use  $1\frac{1}{2}$ " x  $1\frac{1}{2}$ " perforated square tube stringers.
- 3. Punch holes round for  $\frac{3}{8}$ " bolt.

NORTH DAKOTA	
DEPARTMENT OF TRANSPORTATION	
12-1-10	
REVISIONS	
DATE	CHANGE
8-30-18 8-30-19	Updated notes to active voice. New Design Engineer PE Stamp.

This document was originally
issued and sealed by
Kirk J Hoff,
Registration Number
PE-4683,
on 8/30/19 and the original
document is stored at the
North Dakota Department
of Transportation