


## SIGN PUNCHING, STRINGER AND SUPPORT LOCATION DETAILS - ROUTE MARKER SIGNS




## Notes:

- 1. Use 0.100 inch minimum thickness sign backing material.
- 2. Use 1½"x1½" perforated square tube stringer.
- 3. Punch holes round for \%" bolt.








- Stringers

- 10½" -



NORTH DAKOTA DEPARTMENT OF TRANSPORTATION	
8-22-12	
REVISIONS	
DATE	CHANGE
	Updated notes to active voice. New Design Engineer PE Stamp.

This document was originally issued and sealed by Kirk J Hoff, Registration Number PE-4683, on 9/04/19 and the original document is stored at the North Dakota Department of Transportation