
SIGN PUNCHING, STRINGER AND SUPPORT LOCATION DETAILS - ROUTE MARKER SIGNS



Note

- 1. Use 0.100 inch minimum thickness sign backing material.
- 2. Use 1½"x1½" perforated square tube stringers.
- 3. Punch holes round for \%" bolt.

NORTH DAKOTA
DEPARTMENT OF TRANSPORTATION
9-25-12
REVISIONS
DATE CHANGE
8-30-18 Updated notes to active voice.
9-05-19 New Design Engineer PE Stamp.

issued and sealed by
Kirk J Hoff,
Registration Number
PE-4683,
on 9/05/19 and the original
document is stored at the
North Dakota Department
of Transportation

This document was originally