

## **SIEVE VERIFICATION PROCEDURE #1A**

Revised 4/24/2002

Equipment Checked:                    **SIEVES (FINES)**

Purpose:

This method provides instructions for checking the physical condition of laboratory tests sieves ranging in size from 75 mm (3 in.) to 0.075 mm (No. 200).

Inspection Equipment Required:

1.     Visual Inspection

Tolerance:

Sieves shall meet the physical requirements specified in AASHTO M 92 (ASTM E 11).

Procedures:

(Steps 1 & 2 apply only to sieves having openings greater than 4.75 mm).

1.     Select an adequate number of individual sieve openings (3 or 4) along a 45Eline. Measure and record the sieve openings to verify that the size opening indicated on the label is correct.
2.     Repeat step 1, rotating the sieve 90E.
3.     Inspect the general condition of the sieve. Check the frame and solder joints for racks or holes (check for pin holes in the finer sieves).
4.     Make sure the sieve has an appropriate label.
5.     Check for tightness of the wires on each individual sieve.

## EQUIPMENT CALIBRATION RECORD

Calibration Procedure No. 1a Fine Sieves (AASHTO M 92)

<b>Date:</b>	<b>Calibrated by:</b>
<b>Previous Calibration Date:</b>	<b>Next Due:</b>
<b>Frequency:</b> 12 Months	
<b>Calibration Equipment:</b>	
Visual Inspection	

Sieve	Sieve I.D	Visual Inspection (Waviness, dents, scratches, or looseness)		Action Recommended	
				Accept	Replace
No.8 (2.36mm)					
No.10 (2.00mm)					
No.16 (1.18mm)					
No.30 (600µm)					
No.40 (425µm)					
No.50 (300µm)					
No.100 (150µm)					
No.200 (75µm)					

4/25/2002