MECHANICAL COMPACTION HAMMER VERIFICATION PROCEDURE #6A

Revised June 14, 2002

Equipment Checked: MECHANICAL COMPACTOR (AASHTO T 99) (AASHTO T 180)

Purpose:

This method provides instructions for checking the critical dimensions and drop of the proctor hammer.

Inspection Equipment Required:

- 1. Calipers readable to 0.001 inches
- 2. Tape measure readable to 1/16 inch.
- 3. Balance, capacity 5 kg (5000 g) readable to 1 g.
- 4. Molds

Tolerance:

Equipment shall meet the dimensional tolerances specified in the applicable test method.

Procedure:

- 1. Measure and record the diameter of the rammer face by taking two readings 90E apart.
- 2. Determine and record its mass to the nearest 1 g.
- 3. Determine and record the drop of the hammer 18.00 ± 0.06 inches (T180); 12.00 ± 0.06 inches (T 99).
- 4. Mechanical rammer shall be calibrated by ASTM D2168 Method B to give the same moisture density results as with a manually operated rammer. CENTRAL LAB USE ONLY.

EQUIPMENT CALIBRATION RECORD

Calibration Procedure No. 6A Mechanical Rammer Proctor (AASHTO T 99 & T 180)

Date:	Calibrated by:	
Previous Calibration Date:	Next Due:	
Frequency: 12 months		
Manufacturer:		
Action Recommended: Repair Replace No	one Other	
Calibration Equipment	Serial Number	
Calipers, readable to 0.001"		
Balance, 5,000 g, readable to 1 g		
Tape Measure Readable to 1/16"		
Rammer Diameter #1	#2	
Weight	Drop	

Diam	neter	Fall	Weight
T-99	1.985 - 2.010"	12± 1/16"	5.48 - 5.52 lb.
T-180	1.985 - 2.010"	18± 1/16"	9.98 - 10.02 lb.